


48V 15A LEAD ACID Battery Charger

Part Number: CGR-630

Description: CHGR-4815-LA (Lead Acid)



OPERATORS MANUAL

Serial number:

Purchase date:

INSTRUCTIONS:

Thank you for purchasing our product. Please read the entire instructions before use. The CGR-630 Lead Acid 48V 15A charger is an economic, high quality 100-240V AC SMART charger for Lead Acid batteries.

The charging program consists of 5 STAGES: Pre-charge, constant current mode 1, constant current mode 2, constant voltage, and float mode charging. The chargers provide protection against overload, over-voltage, over-heating, short circuit and reverse polarity connections. The charger also has a 15 DAY recharge to keep your batteries topped off.

PLUGS:

Your charger ships with a short cord SB50 GREY quick disconnect. The Vehicle Gender specific cords for Club Car, E-Z-GO, Yamaha, are ordered separately. Please ensure SB50 QD connectors are tight before use. Observe polarity!



SPECIFICATIONS:

	DC Output	
Maximum DC output voltage	58.8V	
Maximum DC output current	15A	
Maximum DC output power	850W	
Nominal DC output current	15A @ 110VAC, 15A @ 220VAC	
Battery type	Lead Acid 48V ONLY	
	AC Input	
AC input voltage range	85-265VAC (With 16AWG IEC C13/C14 Connector)	
Nominal AC input voltage	100-240VAC	
Nominal AC input frequency	50 / 60Hz	
Maximum AC input current	10A~110VAC, 5A~220VAC	
Nominal AC input current	6A~110VAC, 3A~220VAC, (Float mode <1A)	
Power factor	>0.9pf	
	Mechanical	
Dimensions	L*W*H = 28.2 x 12.97 x 7.3 cm (11.1 x 5.1 x 2.87")	
Weight	7 lbs (3.2 kg) (Including charger, AC cable only, DC cable separate)	
Cooling	Active cooling with fan	
	Environmental	
Enclosure	IP66	
Humidity	5% — 95%	
Operating temperature	-20°C to +65°C (-4°F to 149°F), Derated at >40°C (104°F)	
Storage temperature	-40°C to +85°C (-40°F to 185°F)	


EXPLANATION OF LED STATUS:

LED	Charger Status
1. LED solid green.	The charger is ready to charge, or Charging is complete.
2. Red or yellow or green light blinks one time per second.	Red light: SOC<80%, Yellow light: SOC<90%, Green light: SOC<100%
3. Red light blinking quickly.	Input power failure.
4. Red and Green light blinks alternately.	Short circuit or reversed.
5. Red light blinks 2 times, interval 1 second, blinks 2 times again.	Charger temperature over-heating alarm.
6. Red light blinks 3 times, interval 1 second, and then blinks 3 times.	Output over-current alarm.
7. Red light blinks 4 times, interval 1 second, then blinks 4 times.	Output over-voltage alarm.



WARNING AND SAFETY NOTES:

- Battery manufacturers recommend NEW batteries to CHARGE THE BATTERY FIRST BEFORE DRIVING IT. It takes 2-3 discharge/recharge cycles to balance a NEW battery.
- Never leave the charger unattended when it is connected to its power supply.
- The allowable AC input voltage is 100-240VAC, 50/60Hz. Never connect it to any other voltage.
- Never place the charger and batteries connected to it on any form of flammable surface.
- Never operate the charger in the vicinity of flammable material or gas.
- Do not submerge the charger in liquids.
- Ensure that there is unrestricted airflow to and from the charger's cooling slots. Never place the charger on a carpet or similar surface.
- Do not overload AC circuits, the charger may need a full 15amp circuit.
- Do not short circuit the terminals.
- Take great care to maintain correct battery polarity. (STICKER ON UNIT HAS WIRE COLOR AND POLARITY)
- Read the battery manufacturer's instructions and adhere to them strictly.



Recycle Electronic Component





DRIVE, CHARGE, DRIVE, REPEAT.



RHOX chargers are highly efficient, very compact, and most important, Durable.

